

# **MK project Area 2 Camera specifications Documentation EN Blueprint**

R5

Made for : Daifuku (Thailand) Ltd., Meiji (Thailand) Co.,Ltd.  
By : TOMAS TECH CO.,LTD.

---







## **TOMAS TECH**

**TOMAS TECH CO.,LTD.**

7/1 (3C) Udomsuk 46 Alley, Khwaeng Bang Na, Khet Bang Na, Bangkok 10260 Thailand  
Tel :+66-98-271-9741 E-mail : info@tomastc.com

Revision History

Date	Version	File name	Details
31/Oct/2022	R1	MK project Area 2 Camera specifications Documentation EN Blueprint	First edition
01/Nov/2022	R2	MK project Area 2 Camera specifications Documentation EN Blueprint	Second edition 
10/Nov/2022	R3	MK project Area 2 Camera specifications Documentation EN Blueprint	Third edition 
14/Nov/2022	R4	MK project Area 2 Camera specifications Documentation EN Blueprint	4th edition 
05/Feb/2023	R5	MK project Area 2 Camera specifications Documentation EN Blueprint	5th edition 

## ■ Contents

1. Overview
2. Overall configuration diagram
3. System functional specifications
4. Drawing
5. Q&A
6. Sign off

## 1. Overview


A Keyence camera takes a picture of a package being transported on a conveyor. By using a barcode reader, scan information and link the captured information. Each information is stored on Daifuku's server via Ethernet.

## 2. Overall configuration diagram

Overall configuration diagram image (Hardware configuration)

2

#	Item	Qty	IP address	Preparation By
1	Server PC for WMS Windows server	1		Daifuku
2	Server PC for WCS Windows server	1		Daifuku
3	FCC PLC Omron	1		Daifuku
4	Camera Controller CVX350F	7		Keyence
5	Camera PLC Keyence KV7500	7		Keyence
6	Ethernet unit KVXLE02	7		Keyence
7	Camera CAH500C	14		Keyence
8	Camera cable CACH10	14		Keyence
9	BCR cable 2106182	7		SICK
10	BCR cable 6052945	7		SICK
11	SICK Controller 1064114	7		SICK
12	Scanner SICK 1056608+2062452	7		SICK
13	Control box of Daifuku	1		Daifuku
14	Camera Stand	14		Tomas
15	Ethernet HUB	14		Tomas
16	Control box of Tomas Tech	7		Tomas
17				
18				
19				




# 2. Overall configuration diagram

Overall configuration diagram image (Installation configuration)

2

#	Item	Qty	IP address	Preparation By
1	Server PC for WMS Windows server	1		Daifuku
2	Server PC for WCS Windows server	1		Daifuku
3	FCC PLC Omron	1		Daifuku
4	Camera Controller CVX350F	7		Tomas
5	Camera PLC Keyence KV7500	7		Tomas
6	Ethernet unit KVXLE02	7		Tomas
7	Camera CAH500C	14		Tomas
8	Camera cable CACH10	14		Tomas
9	BCR cable 2106182	7		Daifuku
10	BCR cable 6052945	7		Daifuku
11	SICK Controller 1064114	7		Tomas
12	Scanner SICK 1056608+2062452	7		Daifuku
13	Control box of Daifuku	1		Daifuku
14	Camera Stand	14		Tomas
15	Ethernet HUB	14		Tomas
16	Control box of Tomas Tech	7		Tomas
17	Power and Lan wiring to Control box of Tomas Tech	7		Daifuku
18				
19				




## 2. Overall configuration diagram

Overall configuration diagram image (Network group)

2


#	Item	Qty	IP address	Network group
1	Server PC for WMS Windows server	1		Server group
2	Server PC for WCS Windows server	1		Server group
3	FCC PLC Omron	1		FCC group
4	Camera Controller CVX350F	7		Server group
5	Camera PLC Keyence KV7500	7		Server group / FCC group
6	Ethernet unit KVXLE02	7		Server group
7	Camera CAH500C	14		Server group
8	Camera cable CACH10	14		Server group
9	BCR cable 2106182	7		FCC group
10	BCR cable 6052945	7		FCC group
11	SICK Controller 1064114	7		FCC group
12	Scanner SICK 1056608+2062452	7		FCC group
13	Control box of Daifuku	1		FCC group
14	Camera Stand	14		FCC group
15	Ethernet HUB	14		FCC group
16	Control box of Tomas Tech	7		Server group / FCC group
17				
18				
19				



### 3. System functional specifications

#### System processing list

3



① Send trigger signal from FCC PLC Omron to Camera PLC Keyence (FCC Omron PLC → Camera PLC Keyence)  
Communication method: I/O


② Send scan signal from Camera PLC Keyence to SICK Controller (Camera PLC Keyence → SICK Controller) Communication method: I/O  
 ③ Scan signal is sent from SICK Controller to Scanner SICK (SICK Controller → Scanner SICK)  
 Communication method: SICK scanner communication  
 ④ Barcode scanning  
 ⑤ Send barcode data from Scanner SICK to Camera PLC Keyence (Scanner SICK → Camera PLC Keyence) Communication method: Ethernet  
 ⑥ Send barcode data from Camera PLC Keyence to FCC Omron PLC (Camera PLC Keyence → FCC Omron PLC)  
 Communication method: Socket communication\*2

② Send the shooting signal from Camera PLC Keyence to Camera Controller CVX350F (Camera PLC Keyence → Camera Controller CVX350F)  
 Communication method: Ethernet  
 ③ Send the shooting signal from Camera Controller CVX350F to Camera CAH500C (Camera PLC Keyence → Camera Controller CVX350F)  
 Communication method: Keyence CV communication  
 ④ Shooting  
 ⑤ Send image data from Camera CAH500C to Camera Controller CVX350F (Camera Controller CVX350F → Camera PLC Keyence)  
 Communication method: Keyence CV communication  
 ⑥ Send image data from Camera Controller CVX350F to Camera PLC Keyence Communication method: Ethernet  
 ⑦ Rename processing of image data with Camera PLC Keyence  
 ⑧ Send image data from Camera PLC Keyence to Server PC for WCS Windows server  
 (Camera PLC Keyence → Server PC for WCS Windows server) Communication method: FTP




### 3. System functional specifications

System flowchart for Scan process



### 3. System functional specifications

System flowchart for shooting process



## 4. Drawing





43						
42						
41						
40						
39						
38						
37						
36						
35						
34						
33						
32						
31						
30						
29						
28		PFP-100N	DIN RAIL	3	OMRON	
27		BMS3	DIN RAIL STAND OFF	2	IDEC	
26		BMN7	MARK STRIP	2	IDEC	
25		BMN3	MARK STRIP END	2	IDEC	
24						
23		BNC230	UPPER DUST COVER	1	IDEC	
22		BNC240	LOWER DUST COVER	1	IDEC	
21						
20	TB1	BMDH15W	TERMINAL	15	IDEC	
19		BMDL15W	END PLATE	1	IDEC	
18						
17						
16						
15						
14		PFP-M	STOPPER	12	OMRON	
13		BML6	STOPPER	2	IDEC	
12		BNJ26FWPN10	JUMPER	5	IDEC	
11						
10		W25XH65	WIRE DUCT	1	PIYA	
9		W33XH65	WIRE DUCT	1	PIYA	
8		W45XH65	WIRE DUCT	1	PIYA	
7						
6						
5						
4						
3						
2						
1						

156						
155						
154						
153						
152						
151						
150						
149	ICE	CE-08	CONTROL BOX	1	TEMCO	
148						
147						
146	CR1N1-4, CR46100-3	G6D-F4B	RELAY	2	OMRON	
145		G6D-4-SB	SHORT BAR	4	OMRON	
144						
143	RECP1	WK3004-250K	RECEPTACLE	1	PANASONIC	
142						
141						
140	VS1	CV-X320R	VISION CONTROLLER	1	KEYENCE	
139						
138						
134	HUB1, HUB2	IESH-MB205G-R	SWITCHING HUB	2	MISUMI	
133						
132	CP2	CP30FM-1P005	CIRCUIT PROTECTOR	1	FUJIELEC.	
131	CP1	CP30FM-1P007	CIRCUIT PROTECTOR	1	FUJIELEC.	
130						
129	CB1	EW32AAG-2P010B	CIRCUIT BREAKER	1	FUJIELEC.	
128		BW9B1AA-S2	COVER BREAKER	1	FUJIELEC.	
127						
126						
125						
124	MF1	PMF12	FILTER	1	PRIMUS	
123		PMV12.00 220VAC/50Hz	MOTOR FAN KIT	1	PRIMUS	
122						
121						
120	CV2	S8FS-C10024D	POWER SUPPLY	1	OMRON	
119	CV1	S8FS-C20024D	POWER SUPPLY	1	OMRON	
118						
117						
116						
115						
114	PLC1	KV-B8XTD	INPUT 8/OUTPUT 8 UNIT	1	KEYENCE	
113		KV-XLE02	ETHERNET I/P UNIT	1	KEYENCE	
112		KV-7000C	CONNECTION UNIT	1	KEYENCE	
111		KV-7500	CPU UNIT	1	KEYENCE	

PART NAME

1CE DEVICE LIST

DESIGNED

10/2022

SUWACHEE

DRAWN

10/2022

SUWACHEE

APPROVED

CHECKED

CHECKED

TOMAS TECH CO., LTD.

10/2022

10/2022

PART NO.

ASP

SHEET

MARKP102022-AA-0000-TMT

2



2

REMARK

SCALE

MK PROJECT AREA 2 CAMERA UNIT



—




PART NAME									
POWER CIRCUIT DIAGRAM									
TOMAS TECH CO., LTD.					PART NO.				
APPROVED	CHECKED	CHECKED	DESIGNED	DRAWN	MKP102022-AA-0000-TMT				
			10/2022	10/2022	MKP102022-EE-5400-TMT				
			SUNWACHET	SUNWACHET	REMARK				
					MK PROJECT AREA 2 CAMERA UNIT				
					ASP CODE	SHEET			
					Z	1 / 4			
					SCALE	—			









PART NAME				PART NO.			
CONTROL CIRCUIT DIAGRAM (CAMERA CIRCUIT)				MKP102022-AA-0000-TMT			
APPROVED	CHECKED	CHECKED	DESIGNED	10/2022	10/2022	3	4
			SUWACHET	SUWACHET		SCALE	
TOMAS TECH CO., LTD.				MKP102022-EE-5400-TMT			
				MK PROJECT AREA 2 CAMERA UNIT			



L02151  
L02152  
L02153  
L02154  
L02155  
L02156  
L02157  
L02158  
L02159  
L02160  
L02161  
L02162  
L02163  
L02164  
L02165  
L02166  
L02167  
L02168  
L02169  
L02170  
L02171  
L02172  
L02173  
L02174  
L02175  
L02176  
L02177  
L02178  
L02179  
L02180  
L02181  
L02182  
L02183  
L02184  
L02185  
L02186  
L02187

PART NAME									
CONTROL CIRCUIT DIAGRAM (SCANNER CIRCUIT)									
TOMAS TECH CO., LTD.					PART NO.		ASPT		
APPROVED	CHECKED	CHECKED	DESIGNED		DRAWN		REMARK		CODE
			10/2022		10/2022		MK PROJECT AREA 2 CAMERA UNIT		Z
			SWAGHET		SWAGHET				SCALE
									4/4



REMARK: MARK TUBE  
BXXX XX  
BIT 00-15  
WORD 0000-1999

ICE CONTROL BOX

PART NAME

I/O DEVICE 1

TOMAS TECH CO., LTD.

APPROVED

CHECKED

CHECKED

DESIGNED

DRAWN

PART NO.




MKP102022-AA-0000-TMT  
MKP102022-EE-5500-TMT

ASP SHEET  
CODE 1 / 2  
SCALE

REMARK

MK PROJECT AREA 2 CAMERA UNIT

### M/C INTERFACE CIRCUIT DIAGRAM



PART NAME				PART NO.		ASPT CODE	SHEET
I/O INTERFACE BETWEEN M/C							
TOMAS TECH CO., LTD.							
APPROVED	CHECKED	CHECKED	DESIGNED	DRAWN			
			10/2022 SUMACHET	10/2022 SUMACHET	REMARK		2 / 2
				MK PROJECT AREA 2 CAMERA UNIT1			SCALE
							—



For Customer's Approved / Date Approved


Authorized Signature/Company Stamp

Project Name :

Camera Stand -3

Update.	1	2
Design.		
Date.		

Rev.	1	2	3
Design.			
Checker.			
Approved.			
Date.			



Customer Name	MK project_Area 1,2		Tolerance not specified		TOMAS TECH CO.,LTD.	
			Size Classification(mm)	Straight Tolerance(mm)		
Sales.			Below 50	±0.75		
Engineer.			Over 50:Below 500	±1		
Design.			Over 500:Below 1000	±1.75		
Checked			Over 1000:Below 2000	±2		
Approved.			Over2000	±3	DWG NO. SF20221108_1	
Q'ty : 1 Set						
SCALE : 1:6					1 / 1	

5. Q&A

#	Date	Question	By	Date	Answer	By

**6. Sign off**

We hereby acknowledge and agree the above-mentioned blueprint requirements.  
Any changes required after the sign off for this blueprint will be addressed through the change request process.

**Daifuku (Thailand) Ltd.**

**Sign:** \_\_\_\_\_

**Name:** \_\_\_\_\_

**Title:** \_\_\_\_\_

**Date:** \_\_\_\_\_

**Meiji (Thailand) Co.,Ltd.**

**Sign:** \_\_\_\_\_

**Name:** \_\_\_\_\_

**Title:** \_\_\_\_\_

**Date:** \_\_\_\_\_

**TOMAS TECH CO.,LTD.**

**Sign:** \_\_\_\_\_

**Name:** \_\_\_\_\_

**Title:** \_\_\_\_\_

**Date:** \_\_\_\_\_

**## END OF BLUEPRINT##**